

## BARNES TO MOULAMEIN

### BROAD GAUGE

#### 1. CLASS OF LOCOMOTIVE AND PERMITTED SPEEDS (KM/H)

		CLASS OF LOCOMOTIVE		
		G, XR, BL	A, B, GM, N, S	X, H, P, T, Y
BARNES and MOULAMEIN	Freight	-		30
<b>Except</b> Over Edward River Bridge at 371.001 km on Up side of Moulamein	Freight	-		15

**Note** Trains do not operate BARNES – MOULAMEIN line without prior approval.

#### 2. SPECIAL SPEED RESTRICTIONS

No Special Speed Restrictions apply.

#### 3. RULING GRADE LOADS (TONNES)

SECTION	CLASSES OF LOCOMOTIVES												
	G, XR, BL	N	GM, S, X	Mod A	Non-Mod A solo or multi with A	Non-Mod A multi with other class	B	H solo or multi with H, P, T or Y	H multi with other class	T or P solo or multi with H, P, T or Y	T or P multi with other class	Y solo or multi with T, Y, H or P	Y multi with other class
DOWN													
<b>Barnes to MOULAMEIN</b>	..	2650	2370	2500	2500	2500	2070	1900	1710	1700	1530	850	770
UP													
<b>Moulamein to BARNES</b>	..	4180	4180	4180	4180	3760	4180	3140	2830	2930	2460	1940	1740

#### 4. SAFEWORING SYSTEMS

	STATUS – ATTENDED	STATUS – UNATTENDED
BARNES	Attended Junction Station	Unattended Junction Station
MOULAMEIN	Unattended location	Unattended Train Order Terminal Station

Train Order Working is in force between BARNES to MOULAMEIN.

A Proceed and Return Train Order may be issued between ECHUCA / BARNES and MOULAMEIN.

#### 5. SPECIAL NOTES

No Special Notes.

#### 6. DISTANCES FROM MELBOURNE AND CLEAR LENGTH OF CROSSING ROADS

LOCATION	MARKED DISTANCE FROM MELBOURNE (KM) (VIA SEYMOUR)	CLEAR LENGTH OF CROSSING ROADS (LENGTH IN METRES)	
		NO. 1	NO. 2
BARNES	245.120	..	..
WOMBOOTA	262.505	..	..
BUNNALOO	278.700	..	..
CALDWELL	297.127	..	..
WAKOOL	318.021	..	..
BURRABOI	329.065	..	..
MOULAMEIN	372.408	378	378

## NETWORK SERVICE PLAN

**BARNES TO MOULAMEIN**

**BROAD GAUGE**

**7. TRACK CLASS**

Track is maintained to CLASS 4 standards.

**8. PROTECTED LEVEL CROSSINGS**

No Protected Level Crossings.