

**MARIBYRNONG RIVER JUNCTION TO MARIBYRNONG RIVER TERMINAL**

**BROAD GAUGE**

**1. CLASS OF LOCOMOTIVE AND PERMITTED SPEEDS (KM/H)**

		CLASS OF LOCOMOTIVE		
		G, XR, BL	A, B,GM, N, S, X	H, P, T, Y
MARIBYRNONG RIVER JUNCTION and MARIBYRNONG RIVER TERMINAL:				
During daylight	Freight	15	15	15
During inclement weather or darkness	Freight	10	10	10

**2. SPECIAL SPEED RESTRICTIONS**

No Special Speed Restrictions apply.

**3. RULING GRADE LOADS (TONNES)**

SECTION	CLASS OF LOCOMOTIVE												
	G, XR, BL	N	GM, S, X	MOD A	A solo or multi with A	A multi with other class	B	H solo or multi with H, P, T or Y	H multi with other class	T or P solo or multi with H, P, T or Y	T or P multi with other class	Y solo or multi with T, Y, H or P	Y multi with other class
<b>DOWN</b>													
West Tower to MARIBYRNONG RIVER JUNCTION	2790	2135	2135	2135	2135	1830		1420	1420	1420	1420	915	915
MARIBYRNONG RIVER TERMINAL	3000	2260	1900	1900	1900	1710		1190	1070	1190	1070	730	660
<b>UP</b>													
Maribyrnong River Terminal to MARIBYRNONG RIVER JUNCTION	..	..	..	..	..	..		..	..	..	..	..	..
WEST TOWER	2550	1900	1600	1600	1600	1400		820	740	820	740	450	410

**4. SAFEWORKING SYSTEMS**

Siding Conditions Working is in force between MARIBYRNONG RIVER JUNCTION and MARIBYRNONG RIVER TERMINAL.

**5. SPECIAL NOTES**

No Special Notes.

**6. DISTANCE FROM MELBOURNE AND CLEAR LENGTH OF CROSSING ROADS**

LOCATION	MARKED DISTANCE FROM MELBOURNE (KM)	CLEAR LENGTH OF CROSSING ROADS (LENGTH IN METRES)	
		NO. 1	NO. 2
		MARIBYRNONG RIVER JUNCTION	4.43
MARIBYRNONG RIVER TERMINAL	6.80	..	..

**7. TRACK CLASS**

Track is maintained to class standards for sidings.

**8. PROTECTED LEVEL CROSSINGS**

No Protected Level Crossings.

**NETWORK SERVICE PLAN**